## **ASSEMBLY INSTRUCTIONS**

## **FLYCASE WHEELS**

















On the inside of the flycase, put the four screws in the holes.



On the outside, slide the screws into the wheel.







Screw the nut and bold.



Use the special tool to screw.